



IPA Micro-Clean 10 LIQUID

Fast-Acting, Surface Cleaning with a High-pH Cleaner and 10% Isopropanol (IPA) Alcohol

PRODUCT DESCRIPTION

A specially-formulated, micro-cleaning solution containing a high pH cleaner and 10% Isopropanol (IPA) alcohol.

FIELDS OF APPLICATION

- Commercial Buildings
- Corporate Campuses
- Manufacturing Facilities
- Aircraft, Busses, Trains, Vessels
- Community Centers
- Theaters
- Shopping Malls
- Schools
- Transit Centers
- Airports
- Seaports
- Populated Locations
- Jobsites
- Equipment

PACKAGING

Product	Packaging
IPA Micro-Clean 10 LIQUID	1 GAL (3.785 LITER)
	5 GAL (18.925 LITER)
	55 GAL (208.175 LITER)

TECHNICAL DATA

Properties @ 77°F (25°C)

Relative Density (S.G.)	0.96 – 0.98
Freeze Temperature, °F (°C)	-4 (-25)
Initial Boiling Point, °F (°C), ASTM D86	178.0 (81.1)
For cleaning	Water
Color	Blue
Odor	Alcohol
pH	<11
Toxicity	Yes, if consumed
Flashpoint, °F (°C), ASTM D93-11	96 (35.6)
Fumes During Application	Light Alcohol
Environmental Hazards	None
Thinners Required	None
Drying Time	1 - 3 minutes

APPLICATION

Apply product to surface. Allow to set 1 to 2 minutes, then wipe in one direction, folding wipe in half, then in quarter folds with each stroke.

Coverage: Approximately 300-400 ft² / gallon (7.34 – 9.79 m² / liter).

Limitations:

- Temperatures below 34°F (1°C)
- Do not apply to hot surfaces or open flame

- Not intended to sterilize medical devices or apparatus
- Do not dilute or combine with other products
- Not for consumption
- Not intended for personal hygiene

STORAGE

One-year shelf life when stored unopened, in a cool, dry, well-ventilated space. Always agitate, shake or stir before use. Do not allow product to freeze. Freezing may eliminate or reduce effectiveness.

CLEANING

Rinse application tools with clean water.

SAFETY PRECAUTIONS

As with all chemical products, adequate precautions and care must be taken during use and storage. Avoid direct contact with foodstuff, eyes and mouth. If direct contact with eyes or mouth should occur, rinse thoroughly with clean water. Do not contact with open cuts or wounds. Immune compromised or highly sensitive individuals should not use this product.

Certain antidepressants may increase the effects of IPA on sensitive users, even in small amounts. Should headache, dizziness or discomfort occur, seek medical assistance.

TECHNICAL ASSISTANCE

Please contact International Chem-Crete Corporation for Technical Personnel.

WARRANTY

LIMITED WARRANTY: International Chem-Crete Inc. warrants that, at the time and place we make shipment, our materials will be of good quality and will conform to our published specifications in force on the date of acceptance of the order.

DISCLAIMER: The information contained herein is included for illustrative purposes only and to the best of our knowledge, is accurate and reliable. International Chem-Crete Inc. is not under any circumstances liable in connection with the use of information. As International Chem-Crete Inc. has no control over the use to which others may put its products, it is recommended that the products be tested to determine the suitability for specific applications and/or our information is valid in particular circumstances. End-user shall determine the suitability of the product for specific application and assume all responsibility in connection therewith. Rev. 12-1020. V1-DON.



Manufactured by:

International Chem-Crete Inc.,
800 Security Row, Richardson, TX 75081, U.S.A
Tel: (972) 671-6477, Fax: (972) 238-0307
contactus@chem-crete.com • www.chem-crete.com

Chem-Crete Europe, s.r.o.
Stanicna 13, 90851, Holic, Slovakia
Phone: +421 34 66 83 181, Fax +421 34 66 83 119